



STEP 1
Prep floor,
Clean Area



STEP 6
Keep sleeve flush
with existing floor,
ensure tube is
properly aligned



STEP 2
Position tube in
relation to the door
rail to ensure proper
door operation
without
interference



STEP 7
Pour concrete around
tube and insert upright
tube into sleeve insert
while concrete is wet,
properly level tube and
remove upright tube.
allow 2-3 days to cure



STEP 3
Place core drill in
proper location
(7-inch Core bit)



STEP 8
Insert Upright tube
and attach eyebolt



STEP 4
Remove insert and
clean hole of debris



STEP 9
Attach net and
fasten straps tightly



STEP 5
Insert steel
tubing sleeve



STEP 10
Properly Installed
Safety Net