

INSTRUCTION MANUAL

Post Mounted Safety Net

by US Netting



Your Post Mounted safety net ships in one package with all of the necessary hardware included. Congratulations on making your loading dock the safest in the world!



SHIPMENT BREAKDOWN:

- 1 Net
- 2 Baseplates with detachable posts
- 10 Anchor bolts
- 10 Flat washers & nuts (each)
- 8 Eye bolts
- 1 Allen wrench

REQUIRED TOOLS:

Hammer
Socket wrench
Ball pin hammer
Tape measure
Eye & ear protection (recommended)

Please visit www.usnetting.com for a step-by-step installation video.

INSTRUCTIONS:

- 1 Clean the area. Measure 3" from door rail and place post base with at least 1.5" coverage of the door rail. Mark the holes with the enclosed marker.
- 2 Drill holes 3" deep with included drill bit. Note: Make sure to keep inside of holes clean of debris.
- 3 Place base over holes and insert anchor bolts with washer and nut.
- 4 Hammer bolt into bottom of the hole, fasten nut with socket wrench.
- 5 Slide top of post onto base. Repeat steps 1-5 for the second post.
- 6 Attach eye bolt and tighten. The bottom eye bolt holds post top to the base when tightened.
- Attach the net starting with each top hook. Evenly tighten straps by pulling on excess. Wrap loose ends of straps with rubber bands or trim with hot knife.
- 8 Stow by disconnecting from one side and rolling to the other. Hook the top strap to the top eye bolt as shown to the right.





















